

Executive Summary

This document walks through getting a Browan TBHV110 (Health Home Indoor Air Quality) Sensor connected to the Helium network, connected to Cayenne, and capturing data to a Google Sheet via a Pipedream workflow.

Steps

1. Add the device to the console and get data flowing
2. Build and apply a decoder function so you can see/access the sensor data in the payload
3. Build a Cayenne Integration so you can see the data in Cayenne
4. Build a Google Sheet integration so you can see/log/share the data in a spreadsheet

Table of Contents

Contents

Executive Summary.....	1
Table of Contents.....	1
References	1
Add the Device to the Helium Console	2
Build a Decoder and Apply to the Device with a Label	3
Build a Cayenne Integration.....	11
Build a Google Sheet integration	19
Debugging Tips.....	20
Appendix A – JSON Data from Console Debugger	23

References

ID	Topic	Reference	Description
1	TBHV100	<ol style="list-style-type: none"> 1. http://docs.microshare.io/assets/pdf/TBHV110.pdf 2. https://github.com/SensationalSystems/smart_building_sensors_decoder/blob/master/healthyhome.js 	<ol style="list-style-type: none"> 1. Reference Manual for the Browan TBHV110 2. Source code for a decode function
2	Helium	<ol style="list-style-type: none"> 1. https://developer.helium.com/console/adding-devices 2. https://developer.helium.com/console/functions 3. https://developer.helium.com/console/integrations/mydevices-cayenne-integration 4. https://developer.helium.com/console/labels 	<ol style="list-style-type: none"> 1. How to add a device to the console 2. How to create a decoder function 3. How to set up a Cayenne dashboard for your Helium Devices 4. Organizing and Connecting with Labels
3	Pipedream	<ol style="list-style-type: none"> 1. https://github.com/mikedsp/helium/blob/ 	<ol style="list-style-type: none"> 1. How to get data from a Browan

		master/MyDocuments/HowTo_BrowanTBHH100_to_GoogleSheet-SHARE.pdf 2. https://github.com/mikedsp/helium/blob/master/MyDocuments/20200831_TBHV110%20data.xlsx 3. https://pipedream.com/@dangermikeb/tbhv110-to-google-sheet-private-p_ezCn1j	TBHH100 temperature and humidity sensor to flow in real time to a Google Sheet. 2. Example data sample from the Google Sheet 3. Pipedream workflow to get data from the Helium Console to the Google Sheet

Add the Device to the Helium Console

Using the instructions at the following URL, add the device to your Helium Console:

- <https://developer.helium.com/console/adding-devices>

Devices

+ Import Devices + Add New Device

5 Devices Quick Action										
<input type="checkbox"/>	Device Name	Device EUI	Labels	Integrations	Frame Up	Frame Down	Packets Transferred	DC Used	Date Activated	Last Connected
<input type="checkbox"/>	TBHH100915012992-wAppkey	58A8CB0000118F13					0	0	Aug 17, 2020 8:27 PM	
<input type="checkbox"/>	TBHH100	58A8CB000011C1D4	TBHH100 × tbhh100-int ×	TBHH100-to-Pipedream-Private, TBHH100-to-Pipedream-Public, cayenne-TBHH100	1416	2	370	280	Aug 3, 2020 5:58 PM	Aug 26, 2020 4:16 AM
<input type="checkbox"/>	TBHV110	58A8CB000011E251			2	1	3	1	Aug 26, 2020 5:53 AM	Aug 26, 2020 5:59 AM
<input type="checkbox"/>	Miko'sBOL	58A8CB00002023B1	gps_function × cayenne1 ×	Gary's BOL to Pipedream, cayenne-1	2406	2	5695	417	Jul 15, 2020 5:01 PM	Aug 26, 2020 3:58 AM
<input type="checkbox"/>	Gary'sBOL	58A8CB00002024B8	gps_function × Integration_Gary'sBOLtoCayenne ×	Gary's BOL to Pipedream, Gary'sBOLtoCayenne	3686	1	2324	819	Aug 3, 2020 5:56 PM	Aug 26, 2020 4:24 AM

(above) TBHV110 added to the Console and data is flowing

Build a Decoder and Apply to the Device with a Label

Using the instructions at the following URL, create a decoder function and apply it to the device:

- <https://developer.helium.com/console/functions>

Fortunately, someone has already written a decoder function and shared it in the following GitHub repository:

- https://github.com/SensationalSystems/smart_building_sensors_decoder/blob/master/healthyhome.js

Here are the steps to go through:

1. Create a label called 'TBHV110decoder'
2. Create a new custom function
 - a. Name it 'TBHV10decoderFunction' to make it easy to identify in the Console
 - b. Copy and paste in the function code
 - c. Apply the label called 'TBHV110decoder' to the function
3. Go back to the Devices tab of the Console and apply the 'TBHV110decoder' label from the previous step to the TBHV110 device
4. While looking at the TBHV110 device in the Console, turn on the debugger and wait for data to flow
Hint: Move the device into or out of your freezer to trigger a temperature event. Even doing that, it took about 10-15 minutes before I started seeing data in the debugger
5. Once the Console/debugger receives a data packet from the device, verify you can see the decoded data, which should look similar to screenshot below

```
"decoded": {
  "payload": {
    "batt": 3.6,
    "bytes": [
      0,
      11,
      55,
      57,
      244,
      1,
      0,
      0,
      25,
      0,
      55
    ],
    "co2": 500,
    "co2_error": false,
    "iaq": 25,
    "rh": 57,
    "rh_error": false,
    "temp_ambient": 23,
    "temp_board": 23,
    "voc": 0,
    "voc_error": false
  }
}
```

(above) Decoded data from the TBHV110 in the Console debugger

The screenshots below illustrate the steps above.

Version 1.0

BrowanTBHV110_HeliumQuickStart-SHARE

Search Console...

Create New Function

Step 1 - Enter Function Details

Enter Function Name

TBHV110decoderFunction Decoder Custom Script

Step 2 - Enter Custom Script

Script Validator

Payload Input


Hexadecimal (eg.

Payload Output

(above) Starting the creation of a new function.

- Name it 'TBHV10decoderFunction' so that is clear what it is
- Type = Custom Script

Note that the function body is empty



https://github.com/SensationalSystems/smart_building_sensors_decoder/b

smart_building_sensors_decoder / healthyhome.js / <> Jump to -

cazagen Add IAQ measurement, and update temperature measurement Latest commit e977f3b on Mi

1 contributor

64 lines (53 sloc) | 1.39 KB

Raw Blame

Code navigation is available!

Navigate your code with ease. Click on function and method calls to jump to their definitions or references in the same repository. [Learn more](#)

```
1 /*
2  * Decoder function for The Things Network to unpack the payload of the Smart Building Sensors
3  *
4  * This function was created by Cameron Sharp at Sensational Systems - cameron@sensational.systems
5  */
6
7 function Decoder(bytes, port) {
8
9   var params = {
10     "bytes": bytes
11   };
12
13   // VOC Measurement
14   voc = (bytes[7] << 8) | bytes[6];
15   if (voc === 65535) {
16     voc_error = true;
17   } else {
18     voc_error = false;
19   }
20
21   // CO2 Measurement
22   co2 = (bytes[5] << 8) | bytes[4];
23   if (co2 === 65535) {
```

(above) Copying the decoder source code from the decoder function in the Sensational Systems GitHub repository

Devices

Integrations

Labels

- CayenneLPPdecoder
- Integration_Gar... 1
- gps_function 2
- Gary's-OL
- TBHV110 1
- tbhh100-int 1
- cayenne1 1

Functions

Organizations

Users

Data Credits

Create New Function

Step 1 - Enter Function Details

Enter Function Name

TBHV110decoder Decoder Custom Script

Step 2 - Enter Custom Script

```
0 function Decoder(bytes, port) {  
1  
2     var params = {  
3         "bytes": bytes  
4     };  
5  
6     // VOC Measurement  
7     voc = (bytes[7] << 8) | bytes[6];  
8     if (voc === 65535) {  
9         voc_error = true;  
10    } else {  
11        voc_error = false;  
12    }  
13  
14    // CO2 Measurement  
15    co2 = (bytes[5] << 8) | bytes[4];  
16    if (co2 === 65535) {  
17        co2_error = true;  
18    } else {  
19        co2_error = false;  
20    }  
21 }
```

Script Val

Payload In

Hexadec

Payload O

(above) Pasting the code into the new decoder function

Devices

Integrations

Labels

- CayenneLPPdecoder
- Integration_Gar... 1
- gps_function 2
- Gary's-OL
- TBHH100 1
- tbhh100-int 1
- cayenne1 1

Functions

Organizations

Users

Data Credits

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

Labels Applied To

Labels are necessary to apply Functions to devices

Add a Label

TBHV110decoder

Add

Attached Labels

(above) Creating/adding a label called 'TBHV110decoder'

Note – in the screenshot above I created 'TBHV110decoder' right here. Don't do that as it leads to trouble later. Create this label before applying it to the decoder function.

The screenshot shows the Helium QuickStart interface. On the left sidebar, the 'Labels' section is active, displaying a list of labels including 'CayenneLPPdecoder', 'Integration_Gar...', 'gps_function', 'Gary's-OL', 'TBHH100', 'tbhh100-int', and 'cayenne1'. A new label 'NEW - TBHV110decoder' has been added and is highlighted with a red box. Below the 'Labels' section, the 'Functions' section is visible, showing a list of functions. The 'Save Function' button is highlighted with a red box.

(above) New label added, then hit the 'Save the function' button


Note – in the screenshot above I created 'TBHV110decoder' right here. Don't do that as it leads to trouble later. Create this label before applying it to the decoder function.

The screenshot shows the Helium QuickStart interface. On the left sidebar, the 'Functions' section is active, displaying a list of functions including 'CayenneLPPdecoder', 'Integration_Gar...', 'gps_function', 'Gary's-OL', 'TBHH100', 'tbhh100-int', 'cayenne1', and 'TBHV110decoder'. The 'TBHV110decoderFunction' is highlighted with a red box. The main area shows a table of functions with columns for Name, Type, and Applied To. The table lists 5 functions: 'TBHV110decoderFunction' (Custom, Applied To: TBHV110decoder), 'CayenneLPPdecoder' (Cayenne LPP, Applied To: CayenneLPPdecoder), 'TBHH100decoder' (Custom, Applied To: TBHH100), 'SmartBuildingSensors' (Custom, Applied To: gps_function), and 'MyBrowanDecoder' (Browan Object Locator, Applied To: gps_function). The 'TBHV110decoderFunction' row is highlighted with a red box.

(above) The TBHV110 function in the Function list

The screenshot displays the Helium console interface for a device named 'TBHV110'. The left sidebar contains a navigation menu with the following items: Devices, Integrations, Labels, Functions, Organizations, Users, and Data Credits. Under the 'Labels' section, several labels are listed with their counts: CayenneLPPdecoder, Integration_Gar... (1), gps_function (2), Gary's-OL, TBHH100 (1), tbhh100-int (1), cayenne1 (1), and TBHV110decoder. The main content area shows the 'Device Details' for 'TBHV110'. The details include: Name (TBHV110), UUID (4271cf9a-024a-4d49-a782-99f9c19fd5a5), Device EUI (58A0CB000011E251), App EUI (58A0CB0000210000), App Key (3C85096332660B17E06EC2F8D450B4C1), Activation Method (OTAA), Attached Labels (TBHV110decoder), and Associated Integrations. The 'Attached Labels' section is highlighted with a red box, and the 'TBHV110decoder' label is shown with a red 'X' icon and a '+ Add Label' button.

(above) Result of applying the 'TBHV110Decoder' label to the TBHV110 device



(above) Looking at the data flowing to the Device with the debugger – and seeing the decoded data

Build a Cayenne Integration

Using the instructions at the following URL, build a Cayenne integration for the device

- <https://developer.helium.com/console/integrations/mydevices-cayenne-integration>

Here are the steps to go through:


1. In the Helium Console, create a new Cayenne Integration
 - a. Name it 'Cayenne-TBHV110'
 - b. Create and apply the label called 'Tbhv110-cayenne-int'
2. In the Helium Console, apply the integration label, 'tbhv110-cayenne-int' to the TBHV110 device

TBHV110 to Cayenne Setup Console Settings		
Console Object	Name	Applied Label(s)
Integration	Cayenne-TBHV110	Tbhv110-cayenne-int
Device	TBHV110	TBHV110decoder Tbhv110-cayenne-int
Function (Decoder)	TBHV110decoderFunction	TBHV110decoder

(above) Helium Console settings for the TBHV110-to-Cayenne Integration

3. In the Cayenne Dashboard, add/create a new Device/Widget
 - a. Add new... > Devices & Widgets > Lora > Helium > Tracknet THS-Temperature and Humidity Sensor
 - b. Change the default name to 'TBHV110'
 - c. Add the DevEUI from the Helium Console
4. Wait for the data to flow into Cayenne

The screenshots below illustrate the steps above.




(above) Integrations tab in the Console, then select 'myDevices Cayenne' button

Channels / Create New Integration


Create New Integration

Step 1 – Choose an Integration Type

Add a Prebuilt Integration




Helium Cargo
HTTP




myDevices Cayenne
HTTP


Add a Custom Integration




HTTP




MQTT



AWS IoT Core



Azure IoT



Google IoT

Step 2 - Verify Details

myDevices Cayenne lets you quickly visualize real-time data sent over the Helium Network. Use a supported device listed on their console or encode the payload with the Cayenne Low Power Payload (Cayenne LPP) format. For more integration information, check developer.helium.com/console/integrations.

Step 3 - Name your Integration

cayenne-TBHV10

Step 4 - Apply Integration to Label (Can be added later)

Labels are necessary to connect devices to integrations

Add a Label Add

Attached Labels

NEW - tbhv110-cayenne-int x

Create Integration

v1.0.1

(above) Fill in the Integration Name, assign a new label, then hit the 'Create Integration' button


- Integration Name = 'cayenne-TBHV110'
- Assign a new label called 'tbhv110-cayenne-int'

The screenshot shows the Helium dashboard with the 'Integrations' tab selected. On the left sidebar, the 'cayenne-TBHV110' integration is highlighted. The main panel displays the 'Integration Details' for 'cayenne-TBHV110'. The integration is of type 'HTTP', is active, and has a unique ID. The 'Devices Piped' section shows 0 connected devices. The 'Downlink URL' and 'Downlink Key' are provided. Below this, the 'Update your Connection Details' section allows for updating HTTP connection details like method, endpoint, and headers. At the bottom, the 'Labels Applied to' section shows the 'tbhv110-cayenne-int' label is attached to the integration.

(above) the cayenne-TBHV110 integration has been created!


The screenshot shows the Helium dashboard with the 'Devices' tab selected. On the left sidebar, the 'TBHV110' device is highlighted. The main panel displays the 'Device Details' for 'TBHV110'. The device has a unique UUID and various identifiers like Device EUI, App EUI, and App Key. The 'Activation Method' is set to 'OTAA'. In the 'Attached Labels' section, the 'tbhv110-cayenne-int' label is shown as being applied to the device, along with the 'TBHV110decoder' label. The 'Associated Integrations' section shows the 'cayenne-TBHV110' integration is linked to this device.

(above) Apply the integration label, 'tbhv110-cayenne-int' to the device



(above) Log into your Cayenne Dashboard and select the 'Add new...' button

Note – The screenshot above happens to show a Tracknet THS-Temperature device. That is from a Helium-Cayenne integration that I set up for my TBHH100 device. We will actually be using that same device type when we set up the TBHV110 in Cayenne. The TBH100 is a TBV110 without the CO2 and VOC sensors. That's why in the screenshot above, there is a 0.00 in both the CO2 and VOC fields.



(above) Add new... > Devices & Widgets > Lora > Helium



[Tracknet OLS-Object Locator Trcker](#) >
Object Locator Tracker



[Tracknet PBS-Push Button Sensor](#) >
Push button sensor



[Tracknet THS-Temperature and Humidity Sensor](#) >
Temperature and Humidity sensor



[Trackware LoRa 3-1 tracking device](#) >
Tracking device



[Turbo Technologies TBS-220](#) >
Geomagnetic Vehicle Detector

(above) Select the 'Tracknet THS-Temperature and Humidity Sensor'

Enter Settings



Tracknet THS-Temperature and Humidity Sensor
Temperature and Humidity sensor

Name

Tracknet THS-Temperature and Humidity Sensor

DevEUI

Activation Mode

Already Registered

Tracking

Location

This device moves

Add device

Enter Settings



Tracknet THS-Temperature and Humidity Sensor
Temperature and Humidity sensor

Name

TBHV110

DevEUI

Activation Mode

Already Registered

Tracking

Location

This device moves

Add device

(above) Change the default name to 'TBHV110'

(above) Name changed to 'TBHV110'

Enter Settings



Tracknet THS-Temperature and Humidity Sensor
Temperature and Humidity sensor

Name

TBHV110

DevEUI

58A0CB00001

Activation Mode

Already Registered


Tracking

Location


This device moves

Add device

(above) Copy and Paste in the DevEUI information which you can get from the Device tab in the Helium Console, then hit the 'Add device' button



(above) The TBHV110 has been added to your Cayenne dashboard and is waiting for data to come over



(above) Cayenne Dashboard showing Overview of data from the TBHV110 – this is the most recent set of received measurements

The Cayenne Dashboard Data view for the TBHV110 device shows the following data:

Timestamp	Device Name	Channel	Sensor Name	Sensor ID	Data Type	Unit	Values
2020-08-31 5:10:52	TBHV110	2	Temperature	241f0fd0-e84e-11ea-b767-3f1a8f...	temp	c	23
2020-08-31 5:10:52	TBHV110	1	Battery Capacity	24400550-e84e-11ea-883c-638d8...	batt	p	
2020-08-31 5:10:52	TBHV110	4	CO2	2443d5e0-e84e-11ea-883c-638d8...	co2	ppm	527
2020-08-31 5:10:52	TBHV110	3	Humidity	244387c0-e84e-11ea-883c-638d8...	rel_hum	p	50
2020-08-31 5:10:52	TBHV110	0	Battery Voltage	241f5df0-e84e-11ea-93bf-d33a96...	voltage	v	3.5999999046326
2020-08-31 5:10:52	TBHV110	100	RSSI	2441da10-e84e-11ea-93bf-d33a9...	rss	dbm	-57
2020-08-31 5:10:52	TBHV110	5	VOC	244116c0-e84e-11ea-a67f-15e30...	analog_sensor	null	
2020-08-31 5:10:52	TBHV110	101	SNR	24444b10-e84e-11ea-883c-638d8...	snr	db	13.1999999809265
2020-08-31 5:00:53	TBHV110	2	Temperature	241f0fd0-e84e-11ea-b767-3f1a8f...	temp	c	23
2020-08-31 5:00:53	TBHV110	1	Battery Capacity	24400550-e84e-11ea-883c-638d8...	batt	p	
2020-08-31 5:00:53	TBHV110	3	Humidity	244387c0-e84e-11ea-883c-638d8...	rel_hum	p	50
2020-08-31 5:00:53	TBHV110	0	Battery Voltage	241f5df0-e84e-11ea-93bf-d33a96...	voltage	v	3.5999999046326
2020-08-31 5:00:53	TBHV110	101	SNR	24444b10-e84e-11ea-883c-638d8...	snr	db	13
2020-08-31 5:00:53	TBHV110	5	VOC	244116c0-e84e-11ea-a67f-15e30...	analog_sensor	null	
2020-08-31 5:00:53	TBHV110	4	CO2	2443d5e0-e84e-11ea-883c-638d8...	co2	ppm	553
2020-08-31 5:00:53	TBHV110	100	RSSI	2441da10-e84e-11ea-93bf-d33a9...	rss	dbm	-64
2020-08-31 4:50:52	TBHV110	3	Humidity	244387c0-e84e-11ea-883c-638d8...	rel_hum	p	49
2020-08-31 4:50:52	TBHV110	1	Battery Capacity	24400550-e84e-11ea-883c-638d8...	batt	p	
2020-08-31 4:50:52	TBHV110	101	SNR	24444b10-e84e-11ea-883c-638d8...	snr	db	-17
2020-08-31 4:50:52	TBHV110	5	VOC	244116c0-e84e-11ea-a67f-15e30...	analog_sensor	null	
2020-08-31 4:50:52	TBHV110	4	CO2	2443d5e0-e84e-11ea-883c-638d8...	co2	ppm	552
2020-08-31 4:50:52	TBHV110	2	Temperature	241f0fd0-e84e-11ea-b767-3f1a8f...	temp	c	23
2020-08-31 4:50:52	TBHV110	0	Battery Voltage	241f5df0-e84e-11ea-93bf-d33a96...	voltage	v	3.5999999046326
2020-08-31 4:50:52	TBHV110	100	RSSI	2441da10-e84e-11ea-93bf-d33a9...	rss	dbm	-102

(above) Cayenne Dashboard showing measurements received from the TBHV110

Build a Google Sheet integration

Using the instructions in *HowTo_BrowanTBHH100_to_GoogleSheet-SHARE.pdf*, build the following data flow:

- TBHV110 > Helium Hotspot > Helium Console > Pipedream > Google Sheet

The only difference between the TBHH100 and the TBV110 is that the TBHV110 has a few more data fields, namely CO2, VO, and IAQ, which stands for 'Indoor Air Quality' and is a calculated value from the sensor measurements. The TBHV110 reference manual explains this in more detail.

▼ params

Columns ☒ structured mode: on
Enter the data to insert into each column. Click + to add columns in structured mode, or turn structured mode off to enter array of column values as an expression — e.g., {{{1,2,3}}}

[0]:	{{steps.convert_out_of_unix_time.\$return_value}}
[1]:	{{event.body.name}}
[2]:	{{event.body.hotspots[0].name}}
[3]:	{{steps.C_to_F.\$return_value}}
[4]:	{{event.body.decoded.payload.rh}}
[5]:	{{event.body.decoded.payload.rh_error}}
[6]:	{{steps.dewpoint_calc_abs.\$return_value}}
[7]:	{{steps.C_to_F_dp.\$return_value}}
[8]:	{{event.body.decoded.payload.co2}}
[9]:	{{event.body.decoded.payload.co2_error}}
[10]:	{{event.body.decoded.payload.voc}}
[11]:	{{event.body.decoded.payload.voc_error}}
[12]:	{{event.body.decoded.payload.iaq}}
[13]:	{{event.body.decoded.payload.batt}}
[14]:	{{steps.C_to_F_BoardTemp.\$return_value}}
[15]:	{{event.body.hotspots[0].rssi}}
[16]:	{{event.body.hotspots[0].snr}}
[17]:	{{event.body.dc.balance}}
[18]:	{{event.body.dc.nonce}}

ARRAY - params.columns

(above) Pipedream workflow – showing the contents of the steps.add_single_row_to_sheet

	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S
1	Date/Time	From Device	Hotspot	Temp Ambient	Rel Humidity (%)	RH error	(Calc) Absol Humidity g water/kg dry air	(Calc) Dew Point	CO2	CO2 error	VOC	VOC Error	IAQ	Battery (V)	Temp Board	rssi	snr	balance	nonce
2	Sat, 29 Aug 2020 22:15:30 GMT	TBHV110	gorgeous-fuchsia-penguin	70 °F	72	FALSE	11.58729967	60 °F	4536	FALSE	325	FALSE	139	3.5	12 °F	-107	-11.80000019	1003507	1
3	Sat, 29 Aug 2020 22:35:31 GMT	TBHV110	clever-orange-mustang	72 °F	56	FALSE	9.37698152	56 °F	5084	FALSE	746	FALSE	165	3.5	12 °F	-48	10.19999981	1003506	1
4	Sat, 29 Aug 2020 22:55:31 GMT	TBHV110	gorgeous-fuchsia-penguin	75 °F	52	FALSE	10.01574163	56 °F	4507	FALSE	312	FALSE	141	3.5	12 °F	-48	12.5	1003505	1
5	Sat, 29 Aug 2020 23:30:31 GMT	TBHV110	gorgeous-fuchsia-penguin	73 °F	53	FALSE	9.605101578	55 °F	3753	FALSE	99	FALSE	123	3.5	12 °F	-106	-16	1003504	1
6	Sat, 29 Aug 2020 23:35:31 GMT	TBHV110	gorgeous-fuchsia-penguin	73 °F	53	FALSE	9.605101578	55 °F	3623	FALSE	81	FALSE	119	3.5	12 °F	-107	-15.80000019	1003503	1
7	Sat, 29 Aug 2020 23:45:31 GMT	TBHV110	gorgeous-fuchsia-penguin	73 °F	52	FALSE	9.421128182	55 °F	3500	FALSE	68	FALSE	117	3.5	12 °F	-52	14	1003502	1
8	Sun, 30 Aug 2020 00:00:31 GMT	TBHV110	clever-orange-mustang	73 °F	53	FALSE	9.605101578	55 °F	3274	FALSE	48	FALSE	111	3.6	73 °F	-105	-12.80000019	1003501	1
9	Sun, 30 Aug 2020 00:10:31 GMT	TBHV110	clever-orange-mustang	73 °F	52	FALSE	9.421128182	55 °F	3159	FALSE	40	FALSE	108	3.6	73 °F	-105	-12	1003500	1
10	Sun, 30 Aug 2020 00:45:32 GMT	TBHV110	clever-orange-mustang	73 °F	52	FALSE	9.421128182	55 °F	2855	FALSE	25	FALSE	101	3.6	73 °F	-105	-11.19999981	1003498	1
11	Sun, 30 Aug 2020 00:50:32 GMT	TBHV110	clever-orange-mustang	73 °F	52	FALSE	9.421128182	55 °F	2722	FALSE	21	FALSE	98	3.6	73 °F	-102	-16	1003497	1
12	Sun, 30 Aug 2020 00:55:32 GMT	TBHV110	clever-orange-mustang	73 °F	52	FALSE	9.421128182	55 °F	2669	FALSE	19	FALSE	96	3.6	73 °F	-106	-11.80000019	1003496	1
13	Sun, 30 Aug 2020 01:00:32 GMT	TBHV110	clever-orange-mustang	73 °F	52	FALSE	9.421128182	55 °F	2681	FALSE	19	FALSE	97	3.6	73 °F	-48	12.80000019	1003495	1
14	Sun, 30 Aug 2020 01:10:32 GMT	TBHV110	gorgeous-fuchsia-penguin	73 °F	51	FALSE	9.23261933	54 °F	2689	FALSE	19	FALSE	98	3.6	73 °F	-54	13	1003494	1
15	Sun, 30 Aug 2020 01:40:32 GMT	TBHV110	gorgeous-fuchsia-penguin	73 °F	51	FALSE	9.23261933	54 °F	2580	FALSE	16	FALSE	96	3.6	73 °F	-51	12.5	1003492	1
16	Sun, 30 Aug 2020 01:45:32 GMT	TBHV110	gorgeous-fuchsia-penguin	73 °F	52	FALSE	9.421128182	55 °F	2413	FALSE	13	FALSE	91	3.6	73 °F	-52	12.5	1003490	1
17	Sun, 30 Aug 2020 01:50:32 GMT	TBHV110	gorgeous-fuchsia-penguin	73 °F	52	FALSE	9.421128182	55 °F	2436	FALSE	13	FALSE	92	3.6	73 °F	-106	-15.5	1003489	1
18	Sun, 30 Aug 2020 02:35:33 GMT	TBHV110	gorgeous-fuchsia-penguin	73 °F	51	FALSE	9.23261933	54 °F	2009	FALSE	7	FALSE	81	3.6	73 °F	-106	-15.5	1003488	1

(above) Data from the TBHV110 in a Google Sheet. The data in columns I-M are data that the TBHV110 has but the TBHH100 does not. The data in columns G and H is calculated (in a Pipedream workflow step) from the data in columns D and E.

The HowTo instructions can be found in GitHub here:

https://github.com/mikedsp/helium/blob/master/MyDocuments/HowTo_BrowanTBHH100_to_GoogleSheet-SHARE.pdf

An Excel file with some collected data can be found in GitHub here:

https://github.com/mikedsp/helium/blob/master/MyDocuments/20200831_TBHV110%20data.xlsx

A public version of the Pipedream workflow can be found here:

https://pipedream.com/@dangermikeb/tbhv110-to-google-sheet-private-p_ezCn1j

Note – the shared workflow at the link above does not show the parameters being pulled from the event and steps and being populated into the Google Sheet step. See the Pipedream workflow screenshot above for what that looks like.


Very Important: When creating the Custom HTTP Integration to send data to Pipedream, it is critical that the label you apply to the Integration be created BEFORE you attach the label to the Integration. If you create the label for the Integration while you are creating the Integration, and then apply that label to the TBHV110 device, Pipedream will NOT get decoded data. I made this mistake when building the TBHH100 and the TBHV110 integrations with Pipedream.

Debugging Tips

If you're working on your Pipedream workflow and trigger data is being received in the workflow, but you can't see or find the readings returned from the Decoder function you created in the Helium Console, then you most likely have your labels wrong. You'll see the decoded values in the Helium Console debugger when you look at your TBHV110 device so you'll know your decode is working, but the sensor values are not showing up in the Workflow event or trigger. If you're in this state, look very closely at your label assignments in the Console.

11 Labels						Quick Action
<input type="checkbox"/>	Labels	Associated Integrations	No. of Devices	Creator	Date	
<input type="checkbox"/>	CayenneLPPdecoder	CayenneLPPdecoder	0	mikeboucher@yahoo.com	Aug 2	
<input type="checkbox"/>	Integration_Gary's BOL to Cayenne	Integration_Gary's BOL to Cayenne	1	mikeboucher@yahoo.com	Aug 2	
<input type="checkbox"/>	gps_function	gps_function	2	mikeboucher@yahoo.com	Aug 1	
<input type="checkbox"/>	Gary's-OL	Gary's BOL to Cayenne	0	mikeboucher@yahoo.com	Aug 4	
<input type="checkbox"/>	TBHH100	TBHH100-to-Pipedream-Private, TBHH100-to-Pipedream-Public	1	mikeboucher@yahoo.com	Aug 7	
<input type="checkbox"/>	tbhh100-int	cayenne-TBHH100	1	mikeboucher@yahoo.com	Aug 9	
<input type="checkbox"/>	cayenne1	cayenne-1	1	mikeboucher@yahoo.com	Jul 25	
<input type="checkbox"/>	TBHV110decoder	TBHV110decoder	0	mikeboucher@yahoo.com	Aug 2	
<input type="checkbox"/>	My_TBHV110	TBHV110-to-Pipedream-Private	1	mikeboucher@yahoo.com	Aug 2	
<input type="checkbox"/>	tbhv110-cayenne-int	cayenne-TBHV110	1	mikeboucher@yahoo.com	Aug 2	

(above) Looking at Labels in the Helium Console. The label, 'My_TBHV110' is the one that I am using to get decoded data to my Pipedream workflow. The label above that is the one I tried first, but notice how it is not associated with an Integration.



Organizing and Connecting with Labels

Devices can be both organized and connected to Integrations with the use of Labels. Labels are simply user defined identifiers, that can be attached to one or more devices, and one or more Integrations. Also multiple Labels can be added to a single device so users can choose to identify devices based on attributes such as geography (e.g., SF) and device type (e.g., temperature or humidity).

Labels provide flexibility to define where to send data from devices. Users can apply a Label to an Integration and that Label can be used to connect a single or multiple devices to that Integration. For example, users could define an internal server as an Integration for initial testing and apply a descriptive Label (e.g., internal_test). After ensuring devices send data, that internal_test Label could easily be replaced by one that maps to a production endpoint (AWS).

Labels need to be created before attaching them to devices and integrations, read more below on how to do both.

(above) Screenshot of the Helium Label documentation – notice the warning about creating labels before attaching them.

The 2 side-by-side screenshots below compare sensor data views in the Pipedream workflow and in the Helium Console debugger (note – rh and temp values are different because the reading are from different times). If in your Pipedream workflow you see decoded payload data, then your Decoder function in the Helium Console is properly applied to the Pipedream integration. If you cannot see decoded payload data in your Pipedream workflow trigger event, check your labels. The screenshots below are for the TBHH100 device, but the concept is the same for the TBHV110.

```

▶ test
▶ steps.trigger.context {8}
▼ steps.trigger.event {7}
  ▼ body {14}
    app_eui: 58A0CB0000210000
    ▼ dc {2}
      balance: 1005869
      nonce: 1
    ▼ decoded {2}
      ▼ payload {4}
        batt: 3.6
        ▼ bytes [8]
          0: 8
          1: 251
          2: 58
          3: 89
          4: 255
          5: 255
          6: 255
          7: 255
        rh: 89
        temp: 26
      status: success
    dev_eui: 58A0CB000011C1D4
    devaddr: 07010048
  ▶ downlink_url https://console.heli

```

(above) TBHH100 in Pipedream

```

{
  "channels": [
    {
      "debug": {
        "req": {
          "body": {
            "app_eui": "58A0CB0000210000",
            "dc": {
              "balance": 1003525,
              "nonce": 1
            },
            "decoded": {
              "payload": {
                "batt": 3.6,
                "bytes": [
                  8,
                  251,
                  64,
                  26,
                  255,
                  255,
                  255,
                  255
                ],
                "rh": 26,
                "temp": 32
              },
              "status": "success"
            },
            "dev_eui": "58A0CB000011C1D4",
            "devaddr": "07010048",
            "downlink_url": "https://console.helium.com/api",
            "fcnt": 1531,
            "hotspots": [
              {
                "channel": 12,
                "frequency": 904.7000122070312,
                "id": "112vq9i6v1w7Tlt5tzDm65k34Q4Lf1rPg3jw",
                "lat": 34.03938329203826,
                "long": -83.90450738638046,
                "name": "gorgeous-fuchsia-penguin",
                "reported_at": 1598729060,
                "rssi": -64,
                "snr": 12.800000190734863,
                "spreading": "SF10BW125",
                "status": "success"
              }
            ]
          }
        }
      }
    }
  ]
}

```

(above) TBHH100 in Console debugger

Appendix A – JSON Data from Console Debugger

The JSON structure below was copied from the Helium Debugger once the TBHV110 was successfully added to the Console and a decoder function was applied.

```
{
  "channels": [
    {
      "debug": {
        "req": {
          "body": {
            "app_eui": "58A0CB0000210000",
            "dc": {
              "balance": 1006185,
              "nonce": 1
            },
            "decoded": {
              "payload": {
                "batt": 3.6,
                "bytes": [
                  0,
                  11,
                  55,
                  57,
                  244,
                  1,
                  0,
                  0,
                  25,
                  0,
                  55
                ],
                "co2": 500,
                "co2_error": false,
                "iaq": 25,
                "rh": 57,
                "rh_error": false,
                "temp_ambient": 23,
                "temp_board": 23,
                "voc": 0,
                "voc_error": false
              },
              "status": "success"
            },
            "dev_eui": "58A0CB000011E251",
            "devaddr": "0A010048",
            "fcnt": 50,
            "hotspots": [
              {
                "channel": 65,
                "frequency": 904.5999755859375,
```

```

    "id": "112kk7sLkuPybrPDE4ZPAYcAXzuPZbV3F2MH5adatdGohmRX5zJW",
    "lat": 34.04490799366432,
    "long": -83.90869057221556,
    "name": "clever-orange-mustang",
    "reported_at": 1598450375,
    "rssi": -37,
    "snr": 12.199999809265137,
    "spreading": "SF8BW500",
    "status": "success"
  }
],
  "id": "4271cf9a-024a-4d49-a782-99f9c19fd5a5",
  "metadata": {
    "labels": [
      {
        "id": "85e80d87-4d40-4b82-ba0a-993d13860c42",
        "name": "TBHV110decoder",
        "organization_id": "27706bf3-96b3-4ccf-ae94-439c44858866"
      }
    ],
    "organization_id": "27706bf3-96b3-4ccf-ae94-439c44858866"
  },
  "name": "TBHV110",
  "payload": "AAs3OfQBAAAZADc=",
  "port": 103,
  "reported_at": 1598450375
}
}
},
  "description": "console debug",
  "id": "no_integration_id",
  "name": "Console Debug Integration",
  "status": "success"
}
],
  "devaddr": "0A010048",
  "device_name": "TBHV110",
  "frame_down": 7,
  "frame_up": 50,
  "hotspots": [
    {
      "frequency": 904.5999755859375,
      "id": "112kk7sLkuPybrPDE4ZPAYcAXzuPZbV3F2MH5adatdGohmRX5zJW",
      "name": "clever-orange-mustang",
      "rssi": -37,
      "snr": 12.199999809265137,
      "spreading": "SF8BW500"
    }
  ],
  "id": "5b0f480b-9ef1-4cb0-a835-fd1600159b37",

```



```

"payload": "AAs3OfQBAAAZADc=",
"payload_size": 11,
"port": 103
}
{
  "channels": [],
  "devaddr": "0A010048",
  "device_name": "TBHV110",
  "frame_down": 7,
  "frame_up": 50,
  "hotspots": [
    {
      "frequency": 923.9,
      "id": "112kk7sLkuPybrPDE4ZPAYcAXzuPZbV3F2MH5adatdGohmRX5zJW",
      "name": "clever-orange-mustang",
      "rssi": 27,
      "snr": 0,
      "spreading": "SF7BW500"
    }
  ],
  "id": "a6f1c0d4-19e3-49e1-b555-e6fca124f912",
  "payload": null,
  "payload_size": 0,
  "port": 103
}
{
  "channels": [
    {
      "debug": {
        "req": {
          "body": {
            "app_eui": "58A0CB0000210000",
            "dc": {
              "balance": 1006186,
              "nonce": 1
            },
            "decoded": {
              "payload": {
                "batt": 3.6,
                "bytes": [
                  0,
                  11,
                  17,
                  75,
                  54,
                  2,
                  0,
                  0,
                  37,
                  0,

```

```

    53
  ],
  "co2": 566,
  "co2_error": false,
  "iaq": 37,
  "rh": 75,
  "rh_error": false,
  "temp_ambient": 21,
  "temp_board": -15,
  "voc": 0,
  "voc_error": false
},
"status": "success"
},
"dev_eui": "58A0CB000011E251",
"devaddr": "0A010048",
"fcnt": 42,
"hotspots": [
  {
    "channel": 65,
    "frequency": 904.5999755859375,
    "id": "112vq9i6viw7TLt5tzDm65k34Q4Lf1rPg3jwgYHd9CVxwadcNW4g",
    "lat": 34.03938329203826,
    "long": -83.90450738638046,
    "name": "gorgeous-fuchsia-penguin",
    "reported_at": 1598447974,
    "rssi": -47,
    "snr": 12,
    "spreading": "SF8BW500",
    "status": "success"
  }
],
"id": "4271cf9a-024a-4d49-a782-99f9c19fd5a5",
"metadata": {
  "labels": [
    {
      "id": "85e80d87-4d40-4b82-ba0a-993d13860c42",
      "name": "TBHV110decoder",
      "organization_id": "27706bf3-96b3-4ccf-ae94-439c44858866"
    }
  ],
  "organization_id": "27706bf3-96b3-4ccf-ae94-439c44858866"
},
"name": "TBHV110",
"payload": "AAsRSzYCAAAIADU=",
"port": 103,
"reported_at": 1598447974
}
}
},

```

```
"description": "console debug",
"id": "no_integration_id",
"name": "Console Debug Integration",
"status": "success"
},
],
"devaddr": "0A010048",
"device_name": "TBHV110",
"frame_down": 6,
"frame_up": 42,
"hotspots": [
{
"frequency": 904.5999755859375,
"id": "112vq9i6viw7TLt5tzDm65k34Q4Lf1rPg3jwgYHd9CVxwadcNW4g",
"name": "gorgeous-fuchsia-penguin",
"rssi": -47,
"snr": 12,
"spreading": "SF8BW500"
}
],
"id": "d135192e-787b-4ffd-8255-dde5b84688c7",
"payload": "AAsRSzYCAAAIADU=",
"payload_size": 11,
"port": 103
```